

NOTES

- ① OR INDICATES GROUND RETURNS (ALL) COLOR, WHITE.
- ② ALL CHASSIS GROUND MUST BE BARE METAL TO METAL CONNECTIONS & SECURELY TIGHTENED. AND SPRAYED WITH "NAPA" BAT. TERMINAL SEALER.
- ③ WHEN ROUTING WIRE, DO IT THE SAME WAY EACH TIME & WHERE POSSIBLE, MAKE CLEAN RIGHT ANGLE TURNS.
- ④ USE SPLIT LOOM 300°F RATED TUBING ON ALL BATTERY CABLES & WIRES WHERE EXPOSED TO HEAT OR ABRASION.

